



Cisco Aironet Dual-Band Omnidirectional Antenna (AIR-ANT2547VG-N)


Last Updated: July 2014

This document describes the Cisco Aironet AIR-ANT2547VG-N Dual-Band Omnidirectional Antenna and provides instructions for mounting it. The antenna is designed for outdoor use with Cisco Aironet Outdoor Access Points (hereafter referred to as access points) with radios operating in the 2.4-GHz and 5-GHz frequency bands.


The following information is provided in this document:

- [Technical Specifications, page 2](#)
- [System Requirements, page 4](#)
- [Safety Precautions, page 4](#)
- [Installation Notes, page 5](#)
- [Obtaining Documentation and Submitting a Service Request, page 6](#)


Technical Specifications

Antenna type	Omnidirectional colinear array	 353086
Operating frequency range	2400–2483 MHz; 5150–5875 MHz	
2:1 VSWR bandwidth	2400–2483 MHz; 5150–5875 MHz	
Nominal input impedance	50Ω	
Gain (2400–2483 MHz)	4-dBi	
Gain (5250–5875 MHz)	7-dBi	
Polarization	Linear	
E-plane 3-dB beamwidth	30° for 2.4-GHz; 14° for 5-GHz	
H-plane 3-dB bandwidth	Omnidirectional	
Length	11.1 in. (28.2 cm)	
Diameter	1.25 in. (3.17 cm)	
Weight	6.0 oz. (170.0 g)	
Connector type	N-Male	
Operating temperature	–40° to 185°F (–40° to 85°C)	
Water/Foreign Body Ingress	IP66, IP67	
Wind rating	100 mph (161 kph) operational 165 mph (265 kph) survival	


Azimuth Radiation Pattern (2.4 GHz)




Elevation Radiation Pattern (2.4 GHz)



Azimuth Radiation Pattern (5 GHz)



Elevation Radiation Pattern (5 GHz)



System Requirements

This antenna is designed for use with the Cisco Aironet Outdoor Access Points.

Safety Precautions



Warning

Do not locate the antenna near overhead power lines or other electric light or power circuits, or where it can come into contact with such circuits. When installing the antenna, take extreme care not to come into contact with such circuits, as they may cause serious injury or death. For proper installation and grounding of the antenna, please refer to national and local codes (e.g. U.S.: NFPA 70, National Electrical Code, Article 810, Canada: Canadian Electrical Code, Section 54). Statement 280

For your safety, read and follow these safety precautions.

1. Before you install an antenna, contact your Cisco account representative to explain which mounting method to use for the size and type of antenna that you are about to install.
2. Find someone to help you—installing an antenna is often a two-person job.
3. Select your installation site with safety, as well as performance, in mind. Remember that electric power lines and phone lines look alike. For your safety, assume that any overhead line can kill you.
4. Contact your electric power company. Tell them your plans and ask them to come look at your proposed installation.
5. Plan your installation carefully and completely before you begin. Each person involved in an installation should be assigned to a specific task and should know what to do and when to do it. One person should be in charge of the operation to issue instructions and watch for signs of trouble.
6. When installing your antenna, follow these guidelines:
 - a. Do not use a metal ladder.
 - b. Do not work on a wet or windy day.
 - c. Do dress properly—wear shoes with rubber soles and heels, rubber gloves, and a long-sleeved shirt or jacket.
7. If the assembly starts to drop, move away from it and let it fall. Because the antenna, mast, cable, and metal guy wires are all excellent conductors of electrical current, even the slightest touch of any of these parts to a power line completes an electrical path through the antenna and the installer.
8. If any part of the antenna system should come in contact with a power line, do not touch it or try to remove it yourself. Call your local power company to have it removed safely.
9. If an accident should occur with the power lines, call for qualified emergency help immediately.

Installation Notes

The antenna is designed to connect to a dedicated antenna port on the access point. No special tools are required to install the antenna.

The antenna is resistant to the full range of outdoor environments. After the antenna is attached to the access point, seal the connections to prevent moisture and other weathering elements from affecting performance. Cisco recommends using a coax seal (such as CoaxSeal) for outdoor connections. Silicone sealant or electrical tape are not recommended for sealing outdoor connections.

Choosing a Mounting Location

The antenna is designed to create an omnidirectional broadcast pattern. To achieve this pattern, the access point should be mounted clear of any obstructions to the sides of the radiating element. If the mounting location is on the side of a building or tower, the antenna pattern is degraded on the building or tower side.

Generally, the higher an antenna is above the ground, the better it performs. A practice is to install your antenna about 5 to 10 ft (1.5 to 3 m) above the roof line and away from all power lines and obstructions.

Tools and Equipment Required

No tools are required to mount the antenna to the access point. However, you may need a 3/4-in. (19-mm) open end or combination wrench (or adjustable wrench) to remove the antenna port covers.

For information about tools required to mount the access point, see the appropriate access point documentation.

Mounting the Antenna

To connect the antenna to the access point, follow these steps:

-
- | | |
|---------------|--|
| Step 1 | If necessary, remove the antenna port cover. |
| Step 2 | Align the antenna's N connector with the appropriate antenna port. |
| Step 3 | Gently push the antenna into the port. |
| Step 4 | Tighten the antenna hand tight. |
-

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>.

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

78-21570-01

© 2013-2014 Cisco Systems, Inc. All rights reserved.